
Meridian 1

Telephone and attendant console installation

Document Number: 553-3001-215

Document Release: Standard 9.00

Date: October 1997

© 1989, 1997

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

December 20, 1989

Standard, release 1.00. Reissued for compliance with Northern Telecom standard 164.0, and to incorporate corrections and updated information.

December 20, 1990

Standard, release 2.00. Updated to include Attendant Supervisory Module (ASM) installation and telephone acceptance tests.

December 1, 1991

Standard, release 3.00. Issued to updated attendant console connections and ASM installation.

Standard, release 4.00 was omitted.

December 31, 1992

Standard, release 5.00. Issued to include updates for X11 release 18.

December 1994

Standard, release 6.00. Issued for X11 release 20 to include editorial changes, indexing, and Global Console updates.

July 1995

Standard, release 7.00. Issued for X11 release 21 changes.

August 1996

Standard, release 8.00. New information and changes to technical content are noted by revision bars in the margins.

October 1997

Standard, release 9.00. New information and changes to technical content are noted by revision bars in the margins.

Contents

About this document	1
Wiring installation	3
Wiring for telephones and attendant consoles	3
Normal operating ranges	7
Attendant consoles	11
Packing and unpacking	11
Installation and removal	11
Designating attendant consoles	21
Cross-connecting attendant consoles	27
Telephones	39
Packing and unpacking	39
Installation and removal	39
Meridian Modular Telephones self-test	49
M2317 telephone self-test	53
M3000 trouble locating	60
Designating telephones	63
Connecting telephones	65
Cross-connecting telephones	68
Add-on modules	77
Packing and unpacking	77
QMT1 and QMT2 add-on modules	77

Faceplate	78
Designating add-on modules	89
QMT3 Lamp Field Array	89
Busy Lamp Field/Console Graphics Module	95
Attendant Supervisory Module (M2250 console)	107
QMT4 and QMT15 handset modules	110
Amplified handset on SL-1 telephones	121
NE-G6QDC amplified handset on SL-1 telephones	122
QKK1 and QKK3 Handsfree unit interface kits	123
QSU1 Handsfree unit	126
Handsfree unit on a QSU71 telephone	127
QKK8 Automatic Answerback	129
QKM11 adapter kit	132
QKM13 Light Probe kit	133
QUT1 power unit and transformer	139
M2000/M2317/M3000 Data Options	148
Meridian Modular Telephones	154
Analog Terminal Adapter	156
Functional description	156
Meridian Communications Adapter and Meridian Programmable Data Adapter	162
Power Supply Board (NTZK models)	170
Power Supply Board (NT2K models)	178
Installing Displays	181
Installing NT2K24WA or NT2K25YL displays on NTZK sets ...	182
Installing NT2K28AA displays on NTZK or NT2K sets	188
Installing NT2K24WA or NT2K25YL displays on NT2K sets ...	193
External Alerter Board	198
Key Expansion Modules	201
Wall mounting	204
Troubleshooting	205

List of figures

Figure 1	
Apparatus designations	2
Figure 2	
Zone cabling and conduit assignment	4
Figure 3	
NE-500/2500-type telephones—limits and cabling	5
Figure 4	
SL-1 telephones—limits and cabling	9
Figure 5	
QCW-type attendant console—limits and cabling	10
Figure 6	
Typical QCW-type attendant console faceplate layout	14
Figure 7	
M1250 assembly drawing (exploded view)	17
Figure 8	
M2250 assembly drawing (exploded view)	18
Figure 9	
Typical key designations for the QCW attendant console	22
Figure 10	
M1250/M2250 key designations in Shift mode (QMT2 not enabled) .	23
Figure 11	
M1250/M2250 key designations in Shift mode (QMT2 enabled)	24
Figure 12	
M1250/M2250 key designations in Unshift mode (QMT2 enabled) . .	25

Figure 13	
M1250/M2250 designations in Unshift mode (QMT2 not enabled) . .	26
Figure 14	
QCW and M1250 attendant console cross-connections	29
Figure 15	
M2250 attendant console cross-connections	33
Figure 16	
SL-1 telephone faceplate	41
Figure 17	
M2000 digital telephone connections	43
Figure 18	
Meridian Modular Telephone connections	47
Figure 19	
Meridian Modular Telephone cross-connections	48
Figure 20	
M2317 digital telephone cross-connections	52
Figure 21	
M3000 Touchphone cross-connections	59
Figure 22	
SL-1 and M1109 telephone connections	65
Figure 23	
NE-500/2500-type telephone cross-connections for PE modules . . .	69
Figure 24	
SL-1 telephone cross-connections	74
Figure 25	
Meridian Modular Telephone cross-connections	75
Figure 26	
QMT1 and QMT2 add-on module faceplate	81
Figure 27	
Add-on module connection to the SL-1 telephone	83
Figure 28	
Add-on module connection to an attendant console	84

Figure 29	
QMT3 Lamp Field Array connections to the attendant console	93
Figure 30	
QMT3 Lamp Field Array connections to the SL-1 telephone	94
Figure 31	
The Busy Lamp Field/Console Graphics Module on the M1250/M2250 attendant console	96
Figure 32	
Volume slider position	97
Figure 33	
Removing the fastening screws	98
Figure 34	
Removing the top cover	99
Figure 35	
Attendant console knockout section	100
Figure 36	
Connecting the BLF/CGM to the attendant console	101
Figure 37	
Support spacer	102
Figure 38	
Positioning the top cover and the BLF/CGM	103
Figure 39	
Attaching the top cover to the attendant console base and BLF/CGM	104
Figure 40	
Identifying the correct grid positions on the main PCB and attaching the ASM	109
Figure 41	
The QMT4 A/B handset module attached and connected to the attendant console	113
Figure 42	
QMT4A, B, and C handset module	118
Figure 43	
QMT15 amplified handset module	119

Figure 44	
Current limiting kit connections	120
Figure 45	
Light Probe PCB connections to an attendant console and SL-1 telephone	137
Figure 46	
QUT1 power unit faceplate	143
Figure 47	
QUT1 power unit connection	144
Figure 48	
M2000/M2317 data terminal and Data Option power supply connection	150
Figure 49	
M3000 data terminal and DTE/computer terminal connection	152
Figure 50	
Exploded view of the M2616/M2016S/M2216ACD telephone	155
Figure 51	
Installing the MCA	168
Figure 52	
M2006/2008 telephone and option boards	172
Figure 53	
M2616/M2216ACD telephone and option boards	173
Figure 54	
Configuration of a local plug-in transformer	176
Figure 55	
Closet power supply configuration	177
Figure 56	
Ribbon cable placement	180
Figure 57	
Display cable routing	183
Figure 58	
Display cable routing	187

Figure 59	
Positioning the display module	189
Figure 60	
Connecting the Display Module Ribbon Cable, NTZK model	190
Figure 61	
Connecting the Display Module Ribbon Cable, NT2K model	191
Figure 62	
Connecting the cable to the display board	194
Figure 63	
External Alerter connecting block configuration	200
Figure 64	
Key Expansion Module connections (bottom view)	203
Figure 65	
Flowchart for troubleshooting MCA	209

List of tables

Table 1	
Terminal connections	6
Table 2	
Z-type cross-connecting wire	28
Table 3	
Inside wiring colors	28
Table 4	
QCW and M1250 attendant console cross-connections	31
Table 5	
M2250 attendant console connections	35
Table 6	
M2250 typical cross-connections	37
Table 7	
M2000 trouble-locating procedures	44
Table 8	
Meridian Modular Telephones self-test steps and results	49
Table 9	
M2317 telephone key/LCD indicator self-tests	54
Table 10	
M2317 trouble-locating procedures	55
Table 11	
M3000 trouble-locating procedures	61
Table 12	
SL-1 and M1109 telephone connections	66

Table 13	
NE-500/2500 telephone connections	67
Table 14	
500/2500 line card pair-terminations for IPE module connectors A, E, K, R	
70	
Table 15	
500/2500 line card pair-terminations for IPE module connectors B, F, L, S	
71	
Table 16	
500/2500 line card pair-terminations for IPE module connectors C, G, M, T	
72	
Table 17	
Z-typecross-connecting wire	73
Table 18	
Inside wiring colors	73
Table 19	
QMT1 key/lamp module address switch settings (SL-1 telephones) .	85
Table 20	
QMT2 key/lamp module address switch settings (SL-1 telephones) .	86
Table 21	
QMT1 module address switch settings (attendant consoles)	87
Table 22	
QMT2 module address switch settings (attendant consoles)	87
Table 23	
Jack numbering for add-on module connection	88
Table 24	
Jack numbering for QMT3 module connection	92
Table 25	
QMT4 A/B handset module wiring harness connections	117
Table 26	
Attendant console and key/lamp add-on module jack numbering . . .	117
Table 27	
SL-1 telephone connections	131

Table 28	
QUT1 power unit fusing	139
Table 29	
QUT1 connections	140
Table 30	
Allowable distance from the QUT1 to the telephone	146
Table 31	
Allowable distance from the QUT1 to the Lamp Field Array module	146
Table 32	
Allowable distance from the QUT1 to the attendant console	147
Table 33	
Connections for the Apple Macintosh to the M2000/M2317 Asynchronous Data Option (ADO)	150
Table 34	
RS-232-C signals and associated pin numbers for M2317 telephones	151
Table 35	
RS-232-C signals and associated pin numbers for the M3000 Touchphone set	153
Table 36	
Connections for the Apple Macintosh to the M3000 Data Option ...	153
Table 37	
Port types compatible with ATA	157
Table 38:	
Flexible Voice and Data feature configuration	159
Table 39	
V.35 CCITT signals supported by the MCA	164
Table 40	
Troubleshooting Meridian Modular Telephones	205

